

## Camera Compatibility

Manufacturer	Model	Type	Sensor Cleaning Kit	Wet & Dry
Canon	EOS 350D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 10D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 1D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 1Ds	Full Frame	SC-4000	SC-4060-3
Canon	EOS 1D Mark II	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 1D Mark II n	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 1D Mark III	Non Full Frame	SC-4020	SC-4070-3
Canon	EOS 1Ds Mark II	Full Frame	SC-4000	SC-4060-3
Canon	EOS 1Ds Mark III	Full Frame	SC-4000	SC-4060-3
Canon	EOS 5D Mark II	Full Frame	SC-4000	SC-4060-3
Canon	EOS 7D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 5D	Full Frame	SC-4000	SC-4060-3
Canon	EOS 20D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 200D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 100D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 500D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 400D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 450D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 300D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 350 D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 30D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS 40D	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS D30	Non Full Frame	SC-4200	SC-4070-3
Canon	EOS D60	Non Full Frame	SC-4200	SC-4070-3
Canon	Rebel (original)	Non Full Frame	SC-4200	SC-4070-3
Canon	400D Rebel Xti	Non Full Frame	SC-4200	SC-4070-3
Contax	N Digital	Full Frame	SC-4000	SC-4060-3
Fuji	Finepix S1 Pro	Non Full Frame	SC-4200	SC-4070-3
Fuji	Finepix S2 Pro	Non Full Frame	SC-4200	SC-4070-3
Fuji	Finepix S3 Pro	Non Full Frame	SC-4200	SC-4070-3
Fuji	Finepix S5 Pro	Non Full Frame	SC-4200	SC-4070-3
Kodak	DCS760	Non Full Frame	SC-4200	SC-4070-3
Kodak	DCS620	Non Full Frame	SC-4200	SC-4070-3
Kodak	DCS620X	Non Full Frame	SC-4200	SC-4070-3
Kodak	DCS 14n	Full Frame	SC-4000	SC-4060-3
Kodak	DCS SLR/c	Full Frame	SC-4000	SC-4060-3
Kodak	DCS SLR/n	Full Frame	SC-4000	SC-4060-3
Konica Minolta	Maxxum 5D	Non Full Frame	SC-4200	SC-4070-3
	Maxxum 7D	Non Full Frame	SC-4200	SC-4070-3
Leica	M8	Non Full Frame	SC-4200	SC-4070-3
Leica	DMR	Full Frame	SC-4000	SC-4060-3
Leica	S2	Full Frame	SC-4000	SC-4060-3

Nikon	D1	Non Full Frame	SC-4200	SC-4070-3
Nikon	D100	Non Full Frame	SC-4200	SC-4070-3
Nikon	D1H	Non Full Frame	SC-4200	SC-4070-3
Nikon	D1X	Non Full Frame	SC-4200	SC-4070-3
Nikon	D200	Non Full Frame	SC-4200	SC-4070-3
Nikon	D2H	Non Full Frame	SC-4200	SC-4070-3
Nikon	D2Hs	Non Full Frame	SC-4200	SC-4070-3
Nikon	D2X	Non Full Frame	SC-4200	SC-4070-3
Nikon	D2Xs	Non Full Frame	SC-4200	SC-4070-3
Nikon	D3 / 3s / 3x	Full Frame	SC-4000	SC-4060-3
Nikon	D300	Non Full Frame	SC-4200	SC-4070-3
Nikon	D3000	Non Full Frame	SC-4200	SC-4070-3
Nikon	D40 / 40x	Non Full Frame	SC-4200	SC-4070-3
Nikon	D5000	Non Full Frame	SC-4200	SC-4070-3
Nikon	D50	Non Full Frame	SC-4200	SC-4070-3
Nikon	D60	Non Full Frame	SC-4200	SC-4070-3
Nikon	D70	Non Full Frame	SC-4200	SC-4070-3
Nikon	D70s	Non Full Frame	SC-4200	SC-4070-3
Nikon	D700	Full Frame	SC-4000	SC-4060-3
Nikon	D80	Non Full Frame	SC-4200	SC-4070-3
Nikon	D90	Non Full Frame	SC-4200	SC-4070-3
Nikon	D40	Non Full Frame	SC-4200	SC-4070-3
Nikon	D40X	Non Full Frame	SC-4200	SC-4070-3
Olympus	E1	Non Full Frame	SC-4200	SC-4070-3
Olympus	E3	Non Full Frame	SC-4200	SC-4070-3
Olympus	E30	Non Full Frame	SC-4200	SC-4070-3
Olympus	E300	Non Full Frame	SC-4200	SC-4070-3
Olympus	E330	Non Full Frame	SC-4200	SC-4070-3
Olympus	E400	Non Full Frame	SC-4200	SC-4070-3
Olympus	E410	Non Full Frame	SC-4200	SC-4070-3
Olympus	E420	Non Full Frame	SC-4200	SC-4070-3
Olympus	E450	Non Full Frame	SC-4200	SC-4070-3
Olympus	E500	Non Full Frame	SC-4200	SC-4070-3
Olympus	E510	Non Full Frame	SC-4200	SC-4070-3
Olympus	E520	Non Full Frame	SC-4200	SC-4070-3
Olympus	E620	Non Full Frame	SC-4200	SC-4070-3
Olympus	E-P1	Non Full Frame	SC-4200	SC-4070-3
Olympus	E-P2	Non Full Frame	SC-4200	SC-4070-3
Olympus	E-PL1	Non Full Frame	SC-4200	SC-4070-3
Panasonic	DMC-G1	Non Full Frame	SC-4200	SC-4070-3
Panasonic	DMC-GF1	Non Full Frame	SC-4200	SC-4070-3
Panasonic	DMC-GH1	Non Full Frame	SC-4200	SC-4070-3
Panasonic	DMC-L1	Non Full Frame	SC-4200	SC-4070-3
Panasonic	DMC-L10	Non Full Frame	SC-4200	SC-4070-3
Pentax	DL	Non Full Frame	SC-4200	SC-4070-3
Pentax	DL2	Non Full Frame	SC-4200	SC-4070-3
Pentax	DS	Non Full Frame	SC-4200	SC-4070-3
Pentax	D	Non Full Frame	SC-4200	SC-4070-3
Pentax	K-m	Non Full Frame	SC-4200	SC-4070-3
Pentax	K-x	Non Full Frame	SC-4200	SC-4070-3
Pentax	K100D	Non Full Frame	SC-4200	SC-4070-3
Pentax	K110D	Non Full Frame	SC-4200	SC-4070-3

Pentax	K200D	Non Full Frame	SC-4200	SC-4070-3
Pentax	K-7	Non Full Frame	SC-4200	SC-4070-3
Pentax	K10D	Non Full Frame	SC-4200	SC-4070-3
Pentax	K20D	Non Full Frame	SC-4200	SC-4070-3
Samsung	GX-10	Non Full Frame	SC-4200	SC-4070-3
Samsung	GX-20	Non Full Frame	SC-4200	SC-4070-3
Sigma	SD9	Non Full Frame	SC-4200	SC-4070-3
Sigma	SD10	Non Full Frame	SC-4200	SC-4070-3
Sigma	SD14	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 100	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 200	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 230	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 300	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 330	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 350	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 380	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 450	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 500	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 550	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 700	Non Full Frame	SC-4200	SC-4070-3
Sony	Alpha 850	Full Frame	SC-4000	SC-4060-3
Sony	Alpha 900	Full Frame	SC-4000	SC-4060-3